

## **Safety Tips – Boom Supports**

1. For safety while performing regular service or maintenance work, the loader is equipped with boom supports.
2. To avoid personal injury service the loader with the boom arms down and the bucket or attachment on the ground. If it is necessary to service the loader with the boom arms raised be sure to engage the boom supports. Never work under or around a loader with raised boom arms without boom supports engaged.
3. The boom supports, when extended, prevent the boom arms from dropping if hydraulic pressure is relieved or the foot control pedals are accidentally cycled.
4. To operate the boom supports, first remove any bucket or attachment from the quick - tach; raise the boom arms to full height and shut off the engine. Raise the boom handles up and push out toward boom arms to extend the boom supports.